

## Installation, operation and maintenance instructions for emergency models

### **SECURO 24 PRO NCR3XDW04C**

#### IMPORTANT SAFEGUARDS

# When using electrical equipment, basic safety precautions should always be followed including the following: READ AND FOLLOW ALL SAFETY INSTRUCTIONS

- Do not use outside
- 2. Do not mount near gas or electric heaters. Equipment should be mounted in locations and heights where it will not readily be subjected to tampering by unauthorized personnel.
- 3. The use of accessory equipment and replacement parts not recommended by the manufacturer may cause an unsafe condition.
- 4. Do not use this equipment for anything other than its intended purpose.
- 5. The voltage rating for this equipment is specified on the product label. Do not connect equipment to any other voltage.

#### **SAVE THESE INSTRUCTIONS**

#### **Specifications**

Type: Addressable exit light for central battery system

Addressing: Automatic, based on factory unique identification number

Communication: Only with Schrack SECURO 24 PRO panels

Mounting: Ceiling, suspended from ceiling

Light source: LED 1W, 50,000h operation, 6000K color temperature

Viewing distance: 46meters

Housing color and material: White plastic/metal

Protection class: III

Dimensions: 254mm x 254mm x 250mm

Cable connection: Max. 2.5mm2 cross-section solid or sleeved twisted wire

Operating mode: Non-maintained / Maintained


Mains voltage: DC 24-32V Max. input current: 0,08A

Constant nominal ambient temperature range: 0°C<Ta<45°C

Protection: IP42 Certificates: CE



| Modes of the LED indicator: ■ Red ■ Green |               |
|---|---------------|
| Status                                    | Led indicator |
| Normal mode, programmed                   | Constant      |
| New device, not programmed                |               |



Unique identifier - SLxxxx00A0 copy this ID into commissioning book next to light's locatation and drawing text

Cable wiring - Connect the mains cable, the LED module to the luminaire using the diagram.

Correct phasing is important because of the communication line.

An incorrect connection will not cause a fault, but an incorrectly connected luminaire will also affect the function of the other luminaires on the line.

**Changing the LED** – Because of the LED's unique design, it can be changed by the manufacturer only.



#### **CAUTION!**

Works on the 24V mains may only be done from qualified personnel considering the local installation requirements. Before installation the supply voltage must be switched off. The device works from SECURO 24 PRO system. The mounting should be done only with the supplied retainers.

#### Important!

In case of maintenance ensure that the device is disconnected from the power.

The producer will not take the responsibility for the damages caused by improper usage.