

Mounting instructions

Typ		Device Attachement with screw	Injection socket diameter x length	Hole pattern no.	Screw-in depth clamping bolt min. - max.
Wöhner	03 950	2 x M6	Ø8,5 x 11	17 + 18	10 - 12
	03 951				
AEG	MC 64	2 x M6	Ø8,5 x 11	7 + 29	10 - 12
	MC 102				
	MC 103				
	MC 162				
ABB	LN 125	2 x M4	Ø6 x 8	5 + 31	8 - 10
	S 701	2 x M5	Ø7 x 9,5	6 + 27	9 - 11
	S 702			6 + 25	
	S 703			8 + 25	
Klöckner-Moeller	NZM 4	2 x M4	Ø6 x 8	13 + 21	8 - 10
	NZM 6			9 + 20	
Siemens	3VE4	2 x M4	Ø6 x 8	11 + 30	8 - 10
	3VE5			5 + 31	
	3VF3			5 + 23	
Vynckier	JS 1	2 x M4	Ø6 x 8	10 + 22	8 - 10
	JS 2				
	XS 1				
	XS 2	2 x M4	Ø6 x 8	14 + 31	8 - 10
	JS 3				
	XS 3				
Terasaki	TOJ-125	2 x M4	Ø6 x 8	12 + 28	8 - 10
	TOJ-160	2 x M5	Ø7 x 9,5	3 + 26	9 - 11
Mitsubishi	NF 30	2 x M4	Ø6 x 8	10 + 24	8 - 10
	NF 50				
	NF 60				
	NF 100	2 x M4	Ø6 x 8	16 + 34	8 - 10
Telemecanique	Integral 63	4 x M5	Ø7 x 9,5	1 + 2 + 32 + 33	9 - 11