

■ INSTRUCTION MANUAL: TERMINAL BLOCKS FOR ALUMINIUM CONDUCTORS


- Installation manual, terminal blocks for aluminium conductors
 - 1. Scrape the stripped end of the conductor carefully, eg. with a knife, to remove the layer of oxide.

Caution:

Do not use brushes, files or emery paper because particles of aluminium can be deposited on other conductors.



2. After removing the layer of oxide, coat the end of the conductor immediately with a neutral grease, e.g. acidand alkali-free Vaseline, and connect it to the terminal immediately.



Repeat the above procedure if at any time the conductor is disconnected and reconnected.



The contact clamps must be tightened after 6-8 weeks
The specified torques must be checked at regular intervals maintenance.
Note: Screw terminals are NOT MAINTENANCE-FREE when using aluminium conductors!
Therefore, the terminal points must be checked regularly. The intervals for maintenance depend on the operating conditions. We recommend measuring the temperature at the contact points, this helps you to optimize the intervals. Schrack Technik recommends the maintenance interval of 1 year

Maintenance note: