



MX Rear connection plate

User Manual





Danger, installation and use by electricians only





Type	M1 (N.m)
MX1	5
MX2	8
MX3	20



Type		M2 (N.m)
MX1/2	ST2.9X10	0.8
MX3	ST3.5X19	2