US Multicom 384 - Contact Board for UPS Status and Alarm Indication

USMULTI384

Mobil Code

Schrack-Info

The MultiCom 384 provides a set of relay contacts for managing UPS alarm notifications and operating states. The board has two removable terminal boards. One of these terminal boards includes the ESD (UPS Emergency Shut Down) and RSD (Remote Shut Down) signals. The board also provides the possibility of associating Battery Working, Bypass, Alarm and Battery Low warnings with potential free contacts on normally close or normally open contacts.

Features

• Max. current 3A at 250V
• Signal-contact customisation
• Normally Open or Normally Close configuration for each contact

DESCRIPTION	AVAILABLE	STORE	ORDER NO.
Plug in board for UPS alarm and status indication with potential free contacts			**USMULTI384**