

External Communication Card Adapter




Mobil Code

USSLOTADAP

Schrack-Info

External housing in which a USNETMA204 or USMULTI302 plug-in card can be installed. In addition to the internal communication slot in the UPS, a second option for a plug-in card can be opened (e.g. USMULTI384 contact card for alarm and status messages and USNETMA204 network card). The connection to the UPS is made via the RS232 interface.

DESCRIPTION	AVAILABLE	STORE	ORDER NO.
Communication card adapter - Allows the use of UPS communication cards USNETMA204 and USMULTI302 via RS232 port on a Schrack UPS / 122x164x81mm (WxDxH) / 0.7kg			USSLOTADAP

