INSTALLATION MANUAL

38120R
















230V | 20W | SMD 2835 | IP44 | Aluminium + acrylic







Complete with driver 600mA.



Warnings:

- 1. Make sure that the product is installed properly before connecting to electricity.
- 2. Do not cover the fitting.
- 3. Maintenance and installation should only be carried out by a professional electrician.

