
INSTALLATION MANUAL

6316




Warnings:

- 1. Make sure that the product is installed properly before connecting to electricity.
- 2. Maintenance and installation should only be carried out by a professional electrician.

INSTALLATION MANUAL


6316




REMOTE CONTROL

Requires 2xAAA batteries. Remove batteries if not used for long period of time.

- LED indicator
- ON/OFF
- Pairing
- **4** Fan speeds: To turn fan ON 1(lowest) to 6 (highest)
- **6** Fan OFF
- 6 Breeze: Fan speeds automatic cycle between 1 to 6
- **7** Reverse function for winter and summer
- Sleep mode
- Vacation mode: Switch on 5 minutes each 2 hours
- Mute sound
- Child lock
- Timer: Fan stops after 2h/4h/8h





- Hanger bracket
- 2 Receiver
- 3 Rod assembly
- Canopy
- **6** Canopy cover
- Motor
- Remote control + holder
 - +2 mounting screws
 - +1.5V (AAA)x2 batteries
- 8 Cover
- **9** Fan blades (3pcs)
- A Screws for blades
- **B** Mounting hardware
- Blade balancing kit

Warnings:

- 1. Make sure that the product is installed properly before connecting to electricity.
- 2. Maintenance and installation should only be carried out by a professional electrician.